




Air Reversible Drill Item No : QE-6111

● The consumable parts ▲ The replacement parts ★ The non-replacement parts



Only tool

Part List QE-6111

	NO.	PART NO.	DESCRIPTION	Q'TY
▲	1	QE-6111P01	Air Inlet	1
▲	2	QE-6111P02	Exhaust Deflector	1
▲	3	QE-6111P03	O-Ring	1
▲	4	QE-6111P04	Housing	1
▲	5	QE-6111P05	Spring Pin	1
▲	6	QE-6111P06	Trigger	1
●	7	QE-6111P07	O-Ring	1
▲	8	QE-6111P08	Pin Valve Rod	1
▲	9	QE-6111P09	Spring Pin	1
●	10	QE-6111P10	O-Ring	1
▲	11	QE-6111P11	Screw	1
●	12	QE-6111P12	Ball Bearing	1
▲	13	QE-6111P13	Rear Plate	1
▲	14	QE-6111T14	Spring Pin (2 PCS)	1 SET
▲	15	QE-6111P15	Cylinder	1
▲	16	QE-6111P16	Rotor	1
●	17	QE-6111T17	Blade (5 PCS)	1 SET
▲	18	QE-6111P18	Front Plate	1
▲	19	QE-6111P19	Pin	1
●	20	QE-6111P20	Ball Bearing	1
▲	21	QE-6111P21	Washer	1
▲	22	QE-6111P22	Internal Gear	1
▲	23	QE-6111P23	Ball Bearing	1
▲	24	QE-6111T24	Pin (2 PCS)	1 SET
▲	25	QE-6111T25	Gear (2 PCS)	1 SET
▲	26	QE-6111P26	Gear Carrier	1
▲	27	QE-6111P27	Ball Bearing	1
▲	28	QE-6111P28	Lock Nut	1
▲	29	QE-6111P29	Lock Nut	1
▲	30	QE-6111P30	Lock Nut	1
▲	31	QE-6111P31	Ball Bearing	1
▲	32	QE-6111P32	Drive Bushing	1
●	33	QE-6111P33	Needle Bearing	1
▲	34	QE-6111P34	Driving Gear Spindle	1
▲	35	QE-6111P35	Front Casing	1

▲	36	QE-6111P36	Angle Housing	1
▲	37	QE-6111P37	Oil Drop	1
▲	38	QE-6111P38	Bevel Gear	1
●	39	QE-6111T39	Ball Bearing (2 PCS)	1 SET
●	40	QE-6111P40	Washer	1
●	41	QE-6111P41	Cylinder Set Screw	1
▲	42	QE-6111P42	Steel Ball	1
▲	44	QE-6111P44	Wrench	1
▲	45	QE-6111P45	Wrench	1
●	46	QE-6111P46	Washer	1
●	43	QE-61M24	Chuck (Φ2.4)	1
		QE-61M25	Chuck (Φ2.5)	1
		QE-61M30	Chuck (Φ3.0)	1
		QE-61M31	Chuck (Φ3.1)	1
		QE-61M32	Chuck (Φ3.2)	1
		QE-61M45	Chuck (Φ4.5)	1
		QE-61M46	Chuck (Φ4.6)	1
		QE-61M58	Chuck (Φ5.8)	1
		QE-61M59	Chuck (Φ5.9)	1