




Air Hydraulic Riveter

Item No : PA-204



Part List

Item No : PA-204



NO.	INDEX NO.	Description	Q'TY	NO.	INDEX NO.	Description	Q'TY
1A	PA-204P1A	Nosepiece (6.4MM)	1	B02	PA-204PB02	O-ring	1
1B	PA-204P1B	Nosepiece (4.8MM)	1	B03	PA-204PB03	O-ring	1
1C	PA-204P1C	Nosepiece (4.0MM)	1	B04	PA-204PB04	O-ring (2PSC)	1SET
1D	PA-204P1D	Nosepiece (3.2MM)	1	B05	PA-204PB05	O-ring	1
1E	PA-204P1E	Nosepiece (2.4MM)	1	B06	PA-204PB06	Spring pin	1
2	PA-204P02	Front housing	1	B07	PA-204PB07	Spring pin	1
3	PA-204P03	Jaw case	1	B08	PA-204PB08	Pin	1
4	PA-204P04	Jaws (3PSC)	1SET	B09	PA-204PB09	Spring pin	1
5	PA-204P05	Jaw pusher	1	B10	PA-204PB10	O-ring	1
6	PA-204P06	Jaw push spring	1	B11	PA-204PB11	O-ring	1
7	PA-204P07	Jaw housing coupler	1	B12	PA-204PB12	O-ring	1
8	PA-204P08	Lock nut	1	B13	PA-204PB13	O-ring	1
9	PA-204P09	Hydraulic Plunger	1	C01	PA-204PC01	Wrench	1
10	PA-204P10	Back Up Ring	1	C02	PA-204PC02	Wrench	1
11	PA-204P11	Plunger Housing	1	C07	PA-304PC07	poly nail bottle	1
12	PA-204P12	Restore spring	1	C08	PA-304PC08	rear cover	1
13	PA-204P13	Plastic ring	1				
14	PA-204P14	Restore spring	1				
15	PA-204P15	Hanger Ring	1				
16	PA-204P16	Sealing cap	1				
17	PA-204P17	Silencer	1				
18	PA-204P18	Lock nut	1				
19	PA-204P19	Air cylinder	1				
20	PA-204P20	Piston Rod	1				
21	PA-204P21	Rubber Cushion	1				
22	PA-204P22	Air Piston	1				
23	PA-204P23	Nut	1				
24	PA-204P24	Air cylinder lid	1				
25	PA-204P25	Trigger	1				
26	PA-204P26	Linker	1				
27	PA-204P27	Press plank	1				
28	PA-204P28	Air valve	1				
29	PA-204P29	Valve spring	1				
30	PA-204P30	Copper wash	1				
31	PA-204P31	Airproof plastic	1				
32	PA-204P32	Airproof spring	1				
33	PA-204P33	Airproof nut	1				
34	PA-204P34	Airproof cover	1				
B01	PA-204PB01	O-ring (2PSC)	1SET				