




Cordless Ratchet Wrench

Item No : DRW-402 / DRW-402L
DRW-301/DRW-301L



● The consumable parts ▲ The replacement parts ★ The non-replacement parts



Part List DRW-402 / DRW-402L DRW-301/DRW-301L

	NO.	PART NO.	DESCRIPTION	Q'TY
●	1	DRW-402P01	Twist	1
●	2	DRW-402P02	Pin	1
●	3	DRW-402P03	Pin	1
●	4	DRW-402P04	Ratchet head	1
●	5	DRW-402P05	Spring	1
●	6	DRW-402P06	Reversing pins	1
●	7	DRW-402P07	Ratchet claw	1
▲	8	DRW-402P08	Eccentric shaft	1
▲	9	DRW-402P09	Sleeve	1
▲	10	DRW-402P10	Connecting rod	1
●	11	DRW-402T11	Spring (2 pcs)	1 SET
●	12	DRW-402T12	Gasket pins (2 pcs)	1 SET
●	13	DRW-402P13	Ratchet head spacer	1
●	14	DRW-402P14	Retaining ring	1
▲	15	DRW-402T15	Extension rod (384 mm) (1/2") (Bearing, Retaining ring)	1 SET
▲	15	DRW-402LT15	Extension rod (484 mm) (1/2") (Bearing, Retaining ring)	1 SET
▲	15	DRW-301T15	Extension rod (384 mm) (3/8") (Bearing, Retaining ring)	1 SET
▲	15	DRW-301LT15	Extension rod (484 mm) (3/8") (Bearing, Retaining ring)	1 SET
★	22	DRW-402T22	Screw (4 pcs)	1 SET
★	23	DRW-402T23	Screw (6 pcs)	1 SET
●	24	DRW-402T24	Right housing, Left housing (2 pcs)	1 SET
★	25	DRW-402T25	Shock-absorbing pins (2 pcs)	1 SET
★	26	DRW-402P26	Speed control panel	1
★	27	---	PCB controller (27, 28, 37)	1 SET
★	28	---	Ratchet body joint arm	1
●	29	DRW-402P29	Switch buttons	1
★	30	DRW-402T30	Switch+PCB controller (27, 28, 30, 37)	1 SET
★	31	DRW-402T31	Screw (3 pcs)	1 SET
★	32	DRW-402P32	Back cover	1
★	33	DRW-402T33	Motor rotors (33, 34, 35, 36)	1 SET
★	34	---	Retaining ring	1
★	35	---	Bearing	1
●	36	---	Motor gear	1
★	37	---	Motor stator	1
★	38	DRW-402T38	Screw (3 pcs)	1 SET
★	39	DRW-402P39	Fixed disk	1
★	40	DRW-402P40	Gasket	1
★	41	DRW-402P41	Internal ring gear	1
★	42	DRW-402T42	Planetary teethes (3 pcs)	1 SET
★	43	DRW-402P43	Planetary bracket	1
★	45	DRW-402P45	Lampshade	1
★	46	DRW-402P46	Lock button	1