
Cordless Grease Gun
Item No : DGG-103

● The consumable parts ▲ The replacement parts ★ The non-replacement parts



Part List DGG-103

	NO.	INDEX NO.	DESCRIPTION	Q'TY
	1	DGG-103T01	Cross Head Screw (4 PCS)	1 SET
	2	DGG-103P02	Clamping Block Left Housing	1
	3	DGG-103P03	Left Housing	1
	4	DGG-103P04	Footplate Left Housing	1
	5	DGG-103P05	Barrel Assembly	1
	6	DGG-103P06	Pump Assembly	1
	7	DGG-103P07	Battery Connector	1
	8	DGG-103P08	Trigger	1
	9	DGG-103P09	Trigger Pressure Spring	1
	10	DGG-103P10	Microswitch	1
	11	DGG-103P11	Lock-on Button	1
	12	DGG-103T12	Ball Head Plunger (2 PCS)	1 SET
	13	DGG-103P13	Speed Adjustor	1
	14	DGG-103P14	PCB Board	1
	15	DGG-103P15	Guide Rail Blocked Piece	1
	16	DGG-103P16	Footplate Right Housing	1
	17	DGG-103P17	Housing Blocked Piece	1
	18	DGG-103P18	Right Housing	1
	19	DGG-103P19	Clamping Block Right Housing	1
	20	DGG-103T20	Cross Head Screw (9 PCS)	1 SET
	21	DGG-103P21	Drum Support Ring	1
	22	DGG-103P22	Sealing Ring	1
	23	DGG-103P23	Copper Gasket	1
	24	DGG-103P24	Tube	1