




Cordless Impact Driver

Item No : DS-1813



Part List DS-18132



NO.	INDEX NO.	DESCRIPTION	Q'TY
1	DB-1813P01	Power Pack	1PC
2	DS-1813T02	Tapping Screw (4 PCS)	1 SET
3	DS-1813P03	Circlips For Shaft	1PC
4	DS-1813P04	Washer	1PC
5	DS-1813P05	Spring	1PC
6	DS-1813P06	Bush	1PC
7	DS-1813P07	Front Gear Housing	1PC
8	DS-1813P08	O Ring	1PC
9	DS-1813P09	Bush	1PC
10	DS-1813P10	Washer	1PC
11	DS-1813T11	Steel Ball (29 PCS)	1 SET
12	DS-1813P12	Spindle	1PC
13	DS-1813T13	Steel Ball (2 PCS)	1 SET
14	DS-1813P14	Impact Block	1PC
15	DS-1813P15	Washer	1PC
16	DS-1813P16	Spring	1PC
17	DS-1813P17	Spring Washer	1PC
18	DS-1813P18	Rubber Ring	1PC
19	DS-1813P19	Washer	1PC
20	DS-1813P20	Spindle	1PC
21	DS-1813T21	Planet Gear (2 PCS)	1 SET
22	DS-1813P22	Torque Pin	1PC
23	DS-1813P23	Washer	1PC
24	DS-1813P24	Gear	1PC
25	DS-1813P25	Ball Bearing	1PC
26	DS-1813P26	O Ring	1PC
27	DS-1813P27	Rear Gear Housing	1PC
28	DS-1813P28	Rubber Ring	1PC
29	DS-1813P29	Circlips For Shaft	1PC
30	DS-1813P30	Motor And Gear ASSY	1PC
31	DS-1813P31	Inner Wire	1PC
32	DS-1813P32	Left Housing Assy	1PC
33	DS-1813P33	F/R Button	1PC
34	DS-1813P34	Switch	1PC
35	DS-1813P35	O Ring	1PC
36	DS-1813P36	PCB Assembly	1PC
37	DS-1813P37	Bracket	1PC
38	DS-1813P38	Handle Hoop	1PC
39	DS-1813P39	Contact Receptacle ASSY	1PC
40	DS-1813P40	Bits Holder	1PC
41	DS-1813T41	Tapping Screw (8 PCS)	1PC
42	DS-1813P42	Right Housing Assy	1 SET