




TORQUE MULTIPLIER

Item No : TM-0428-2



Part List TM-0428-2

	NO.	INDEX NO.	DESCRIPTION	Q'TY
	1	TM-0428-2P01	Main Frame	1
	2	TM-0428-2P02	Input Planet Carrier	1
	3	TM-0428-2P03	Output Planet Carrier	1
	4	TM-0428-2P04	Input Transmission Shaft	1
	5	TM-0428-2P05	Output Transmission Shaft	1
	6	TM-0428-2P06	Input Bearing	1
	7	TM-0428-2P07	Output Bearing	1
	8	TM-0428-2P08	Bearing Bush	1
	9	TM-0428-2P09	Bearing Snap Ring	1
	10	TM-0428-2T10	Input Planet Gear (4 pcs)	1SET
	11	TM-0428-2T11	Output Planet Gear (4 pcs)	1SET
	12	TM-0428-2T12	Input Gear Shaft (4 pcs)	1SET
	13	TM-0428-2T13	Output Gear Shaft (4 pcs)	1SET
	14	TM-0428-2T14	Input Needle Roller (4 pcs)	1SET
	15	TM-0428-2T15	Output Needle Roller (4 pcs)	1SET
	16	TM-0428-2P16	Self-lubricated Bearing	1
	17	TM-0428-2P17	Aluminum Cover	1
	18	TM-0428-2P18	Pawl	1
	19	TM-0428-2P19	Pawl Plate	1
	20	TM-0428-2P20	Graduated Circle	1
	21	TM-0428-2P21	O-ring	1
	22	TM-0428-2P22	Snap Ring	1
	23	TM-0428-2P23	Square Drive	1
	24	TM-0428-2T24	Screw M5 (5 pcs)	1SET
	25	TM-0428-2P25	Screw M8	1
	26	TM-0428-2P26	Pawl Spring	1
	27	TM-0428-2T27	Screw M4 (2 pcs)	1SET
	28	TM-0428-2P28	Anchor	1
	29	TM-0428-2P29	Reaction Bar	1
	30	TM-0428-2P30	Pivot Pin	1
	31	TM-0428-2P31	Ball 6mm	1